

AF13G Parts Breakdown

NO.	DESCRIPTION	Q'TY
A	compressor pump	1
B	engine	1
1	air tank	1
2	belt cover	1
3	pressure gauge	1
4	safty valve	1
5	pilot valve w/release	1
6	drain valve	1
7	stop valve	1
8	check valve	1
9	outlet pipe	1
10	unloading pipe	1
11	outlet elbow	1
12	joint-T	1
13	nipple joint	1
14	idle valve	1
15	tube of idle valve	1
16	engine pully	1
17	key	1
18	inspect plug	2
19	oil-ring	2
20	belt	2
21	bushing joint	1
22	oil pipe joint	1
23	oil pipe nut	1
51	lock bolt for pump	4
52	washer	12
53	spring washer	8
54	lock nut	8
55	lock bolt for engine	4
56	lock bolt for belt cover	4
61	washer	4
62	lock bolt for engine pulley	2

