

AF9 Parts Breakdown

Part Number	Part Description	Q'TY
1	80Gallon Tank 200PSI	1
2	PUMP HEAD	1
3	MOTOR	1
4	PUMP HEAD PULLEY	1
5	PLATE	1
6	KEY	1
7	MOTOR PULLEY	1
8	BELT	2
9	SDS BUSHING	1
10	BELT GUARD (6700-3095)	1
11	PLATE (CAN13570)	1
12	PRESSUER GAUGE Npt 1/4	1
13	NIPPLE JOINT Npt 1/4	1
14	IF10 PRESSURE SWITCH	1
15	AIR VALVE Npt 3/4	1
16	R3/4-Rc3/4 COPPER JOINT	1
17	M27×R3/4 COPPER JOINT	1
18	φ6×R1/8 CUTTING FERRULE JOINT	1
19	OUTLET PIPE(φ19)	1
20	JOINT R2-Rc1/4	1
21	PUMP HEAD RELEASE PIPE (φ6)	1
22	φ6×R1/8 CUTTING FERRULE JOINT	1
23	φ6 RELEASE PIPE	1
24	AIR VALVE Npt 1/4	1
25	SAFETY VALVE Npt 1/4	1
26	PLATE	1
27	ELECTROMAGNETIC STARTER	1
28	SQUARE PLUG Npt 1/4	1
29	FLAT WASHER 10	6
30	FLAT WASHER 12	4
31	LARGE FLAT WASHER 8	4
32	SPRING WASHER 6	3
33	SPRING WASHER 8	14
34	SPRING WASHER 10	1
35	SPRING WASHER 12	4
36	HEX HEAD CAP SCREW M8×20	10
37	HEX HEAD CAP SCREW M8×35	4
38	HEX HEAD CAP SCREW M10×35	1
39	HEX HEAD CAP SCREW M12×50	4
40	HEX HEAD CAP SCREW 1/4-20UNC	3
41	NUT M12	4
42	NUT M8	6

